

ARB FITTING INSTRUCTIONS

ARB ROOF RACK DEFLECTOR

PRODUCT NUMBER

3700320 (1120mm Wide)

3700310 (1250mm Wide)

USE	PART No	QTY	DESCRIPTION
1120 Wide ROOF RACK	6521034	1	DEFLECTOR
1250 Wide ROOF RACK	6521035	1	DEFLECTOR
	6781409	2	VHB ACRYLIC FOAM DOUBLE SIDED TAPE



1. Lightly abrade the areas where the tape will attach on both the roof rack and the air deflector with a scotch-brite pad only enough to take the shine off both surfaces.
2. Clean the front tubes, gussets and inside of air deflector with a clean rag soaked in an isopropyl alcohol based cleaner and wipe off with a clean dry rag. **Always assume that surfaces are dirty as even fingermarks affect the strength of the bond.**
3. Cut double-sided tape into two lengths of approximately 75mm and the remainder in to three lengths of approximately 150mm.



4. Apply tape to the rack as shown leaving the backing tape in place. Press down firmly to ensure a good contact.
5. Remove the backing paper from the tape.
6. Starting at the top of the rack, carefully bring the air deflector into contact with the tape and continue by rolling the deflector down until it contacts the lower edge of the rack.
7. Once satisfied with the location of the air deflector, apply pressure to the tape locations.

* If available use the assistance of another person to ease fitting.

WARNING:- DO NOT USE OIL BASED SOLVENTS OR METHOLATED SPIRITS AS THESE MAY LEAVE AN OILY RESIDUE.