

READYLIFT®

LEVELING SUSPENSION

ReadyLift® (Part# 66-1000) Installation Instructions 02-05 Dodge Ram 1500 4wd

**Please read instructions thoroughly and completely before beginning installation.
Installation by a trained mechanic is recommended**

Step 1:

Position truck on a flat surface and lift vehicle by the frame so that the front wheels are off the ground using a floor jack and jack stands or a (2) two post lift if available. Next locate the torsion key at the rear of the torsion bar under the cab of the truck. (Insert A)

At this time measure the extended length of the front shocks. If the front shocks measure 15.75" or less in length they must be replaced with a 17" maximum length replacement shock. ReadyLift® recommends Pro Comp Part # 917553

Note: Prior to lifting the vehicle it is recommended that you measure the stock height of the vehicle so that you have a base line to gauge when you are adjusting the height of the vehicle. Measuring the vehicle from the bottom of the wheel to the lip of the fender as in (Insert B) is recommended.



(A)



(B)

Step 2:

Remove the torsion key adjusting bolt completely. Using a ReadyLift® Torsion Bar Unloading Tool Part # 66-7822A, and the bracket supplied in the ReadyLift® kit as shown in (Insert C)

Compress the key so that you can remove the threaded part of the torsion adjuster. Releasing the tension on the unloading tool will now release the tension on the torsion bar. Slide torsion bar forward allowing the torsion key to be removed. As in (Insert D)



Insert C



Insert D

ReadyLift Suspension, Inc.

2060 Placentia Ave., Suite B-1, Costa Mesa, CA 92627

Toll Free (800)549-4620 Local (949)515-0795 Fax (949)515-0655



ReadyLift® (Part# 66-1000) Installation Instructions

02-05 Dodge Ram 1500 4wd (cont.)

Step 3:

Install the ReadyLift® Forged torsion key and slide torsion bar back into position as in (Insert E)

IMPORTANT! Make sure Torsion Bar is extended at least ¼inch through the Torsion Key.

Apply pressure with Torsion Bar Unloading Tool to the torsion key, and create enough space to reinsert the torsion key keeper that the adjusting bolt threads into.



Insert E

Step 4:

Reinstall the adjusting bolt, and adjust it so ¼" of bolt threads extend beyond torsion key keeper. **IMPORTANT!** – Each ¼" of adjustment on the bolt equals 1" at the wheel. It is best to check ride height after this initial setting and adjust as needed.

Step 5:

Repeat steps 1 through 3 on the Passenger Side of the vehicle. Follow each step closely making sure to double check the torque on all fasteners. Measure the distance between the tires and fenders to make sure both sides of the truck are even.

Step 6:

Wheel Alignment; a Certified Alignment Technician that is experienced with lifted vehicles is recommended to perform the alignment.

*It is recommended that you have your vehicle's alignment checked whenever installing new tires.

*It is also recommended that you adjust your headlights whenever your vehicle's ride height is altered.

ReadyLift Suspension, Inc.

2060 Placentia Ave., Suite B-1, Costa Mesa, CA 92627

Toll Free (800)549-4620 Local (949)515-0795 Fax (949)515-0655

READYLIFT®

LEVELING SUSPENSION

ReadyLift® (Part# 66-1000) Installation Instructions

02-05 Dodge Ram 1500 4wd (cont.)



Before ReadyLift®



After ReadyLift®

Vehicle Handling Warning

Vehicles with larger wheels and tires will handle differently than stock vehicles.

Take time to familiarize yourself with the handling of your vehicle.

DRIVE SAFELY and WEAR YOUR SEATBELT

Installation Warning

Always wear proper safety equipment and use the correct tools when installing any suspension upgrade. Make sure vehicle is on a flat surface and you are using jack stands or a lift rated for the weight of the vehicle.

Warning! This ReadyLift® Leveling Kit is designed and engineered to level out a stock vehicle with no prior modifications. The use of this kit along with items such as rear lift blocks or spacers, add a leafs, airbags, suspension lifts , body lifts or any other type of lifting accessory shall be done at the vehicles owners risk and will void any and all warranties in effect or implied by ReadyLift®

ReadyLift Suspension, Inc.

2060 Placentia Ave., Suite B-1, Costa Mesa, CA 92627

Toll Free (800)549-4620 Local (949)515-0795 Fax (949)515-0655