



OLD MAN EMU

FITTING INSTRUCTIONS


FK73

Ford Superduty
2008 On F250/350
Bump Stop Spacer Front

HAND TOOLS REQUIRED

Ring / Open end Spanner set (Metric)
Socket Set (Metric)
Hammer

KIT CONTENTS

Part No.	Qty.	Description	Picture
6250019	2	Bump Spacer	
6151240	2	Bolt M8 x 50	
4581044	2	Washer Flat M8	
4581046	2	Washer Spring M8	

Fitment Notes

- This kit should be fitted after raised Old Man Emu suspension Coil Springs have been installed.

Fitting Procedure

1. Remove OE front bump stop by pulling bump stop towards you and it will pop out of the cup mount.



2. Remove bump stop cup mount from chassis by removing M8 fastener found in the centre of cup mount.

3. Flatten tab on cup mount



4. Insert OME bump spacer between chassis and bump stop cup mount. Mount using supplied M8 x 50 Bolts with M8 washers. Torque to 25Nm.



5. Insert bump stop into cup mount.

