

# OPEN FIRST!!



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

## Parts list for Master set # 2-18103

© 2004 Energy Suspension. All rights reserved.  
May not be reproduced, in any form, or by any means,  
without the written consent of Energy Suspension.

### Parts list:

Energy Suspension recommends that you read over all the installation instructions and parts list before you start.

Jeep transmission torque arm grommet set: 2.1101  
2 - 4403 bushings

Transmission mount: 3.1108  
replaces factory part # 1370910

1 - 1036 mount  
1 - 15.810 backing plate  
2 - 15.348 (7/16" lockwasher)  
4 - 15.342 (7/16" flat washer)  
2 - 15.530 (7/16"-14 x 1" bolt)  
1 - 17112 installation instructions

Front leaf spring and shackle bushing set: 2.2102

4 - 2002 main eye bushings  
2 - 15.007 (3/4" O.D. x 9/16" I.D. x 2.900" sleeve)  
8 - 2003 rear spring eye and frame shackle bushings  
1 - 17040 installation instructions

Rear leaf spring and shackle bushing set: 2.2103

4 - 2223 main eye bushings  
2 - 15.007 (3/4" O.D. x 9/16" I.D. x 2.900" sleeve)  
8 - 2005 rear spring eye and frame shackle bushings  
use 17040 installation instructions

Body mount set: 2.4103

8 - 4024 bushings molded in nipple (# molded on part)  
8 - 4022 bushings (.450" hgt. x 1-1/8" I.D.)  
2 - 4023 bushings, molded in sleeve (# molded on part)  
2 - 4021 bushings (.450" hgt. x 7/8" I.D.)  
1 - 4019 bushing (.400" hgt. x .675" I.D.)  
1 - 4017 bushing, molded in nipple (# molded on part)  
1 - 17035 installation instructions

### Parts list continued:

Complete greaseable front swaybar bushing and endlink grommet set: 9.5160  
(15/16" diameter bar)  
2 - 5339 (15/16" greaseable bushings)  
2 - 15.12.06.39 greaseable bushing brackets  
4 - 15.323 washers  
4 - 2201 upper and lower endlink grommets  
1 - 17145 installation instructions

Tie-rod boot sets: 9.13101

4 - 13001 tie-rod boots

Grease:

2 - 9.11101 grease tubs

## Additional parts available for

### Front or rear bump stops

1976-79 all  
replaces O.E. part # J5355483 set # 9-9137

### Shock boots

fits most aftermarket shocks (sold in pairs)  
set # 9-8130

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, etc. please ask to see catalog at your place of purchase.

17187

12/17/96 KN  
Updated 3-12-2004  
Rev.2 5/9/2013 KLB