

# OPEN FIRST!!

## Parts list for Master set # 8.18103 90-95 Toyota 4Runner 2WD/4WD



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2009 Energy Suspension. All rights reserved.  
May not be reproduced, in any form, or by any means,  
without the written consent of Energy Suspension.

### Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start**. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

### Front control arm bushing set: 8.3108 You must reuse all the factory metal parts.

- 2 - 3125 bushings, front upper position
- 2 - 3126 bushings, rear upper position
- 4 - 3129 bushings, front and rear lower position
- 1 - 17019 installation instructions

### Rear control arm bushing and track(panhard) bar bushing set: 8.3107

- 16 - 3127 upper and lower control arm bushings
- 8 - 15.10.121.39 (.875"O.D. x .625" I.D. x 2.562" sleeve)
- 2 - 7047 track bar bushings
- 1 - 15.10.80.39 (.875"O.D. x .625" I.D. x 1.800" sleeve)
- 2 - 7048 track bar bushings
- 1 - 15.03.20.39 (2.00"O.D. x .625" I.D. washer)
- 1 - 15.03.22.39 (2.00"O.D. x 1.188" I.D. washer)
- 1 - 17039 installation instructions
- 1 - 17040 installation instructions

### Front swaybar (24mm)frame bushing and endlink bushing set: 8.5114

- 2 - 5115 (24mm) frame bushings
  - 4 - 4806 endlink grommets
  - 4 - 15.03.01.39 (1-1/4" O.D. x .385" I.D. Cup washers)
- use 17039 installation instructions

### Rear swaybar (18mm)frame bushing and endlink bushing set: 8.5115

- 2 - 5041 (18mm) frame bushings
  - 4 - 4806 endlink grommets
  - 4 - 15.03.01.39 (1-1/4" O.D. x .385" I.D. cup washers)
- use 17039 installation instructions

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

### Parts list continued:

### Tie-rod boot set: 2ea 9.13101

- 4 - 13001 tie-rod boot

### Grease:

- 2 - 9.11113 grease tub

### Additional parts available for your vehicle:

### Shock boot Set: 9.8130

Fits most aftermarket shocks (2 per set)

17206

3/JAN/09 BRH

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.