

OPEN FIRST!!

Parts list for Master set # 4.18102



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2007 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start**. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

Front axle pivot bushing set:

- (3-piece bushing fits in "R" shell)
- 2 - 3228.1 bushings (flanged outer)
- 2 - 3228.2 bushings (center)
- 2 - 3228.3 bushings (outer)
- 2 - "R" shells
- 2 - 15.10.20.39 (.875"O.D. x .563"I.D. x 1.800" sleeve)
- 2 - 3119 thrust washers
- 1 - 17019 installation instructions

Rear leaf spring and shackle bushing set:

- 4 - 2061 main eye bushings
- 2 - 15.10.08.39 (.750"O.D. x .563"I.D. x 3.000" sleeve)
- 4 - 2086 rear spring bushings
- 2 - 15.10.08.39 (.750"O.D. x .563"I.D. x 3.000" sleeve)
- 2 - 2089 frame shackle bushings
- 2 - 2090 thrust washers
- 2 - 15.10.08.39 (.750"O.D. x .563"I.D. x 3.000" sleeve)
- 1 - 17040 installation instructions
- 1 - 17060 installation instructions

Strut(radius) arm bushing set:

- 2 - 7003 bushings
- 2 - 7004 bushings

Front swaybar bushing kit (23mm dia.)

- 2 - 5073 pivot bushings
- 8 - 4902 endlink grommets
- 4 - 15.10.119.39 (.688"O.D.x .500"I.D.x1.320"sleeve)
- 1 - 17039 installation instructions

Rear swaybar bushing kit (15.5mm dia.)

- 2 - 5070 pivot bushings
- 8 - 4902 endlink grommets
- 2 - 15.10.31.39 (.688"O.D.x .500"I.D.x1.375"sleeve)
- 1 - 17039 installation instructions

Tie-rod boot sets:

- 4 - 13001 tie-rod boots

Grease:

- 2 - 9.11101 grease tubs

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.

17188

16/JUL/07 BRH