



advanced FLOW engineering Intake System Cover

Instruction Manual PN: 54-11638-B (Black)

Make: Dodge/RAM	Model: 1500	Year: 2002-2018	Engine: V8-4.7L/5.7L HEMI
Make: Dodge/RAM	Model: 1500 Classic	Year: 2019-2020	Engine: V8-5.7L HEMI

Important! Please read all instruction steps before you begin installation.

Step 1. Remove trim seal from housing ①.

Step 2. Remove only top (3) M6 screws from housing adaptor, keeping adaptor in place. Slide cover down on housing as shown.

Step 3. Reinstall the M6 screws back in place. Your install is now complete!

