



advanced FLOW engineering Intake System Cover Instruction Manual PN: 54-32578-B

Make: **Dodge/RAM**

Model: **1500**

Year: **2014-2018**

Engine: **V6-3.0L (td) EcoDiesel**

Make: **Dodge/RAM**

Model: **1500 Classic**

Year: **2019**

Engine: **V6-3.0L (td) EcoDiesel**

Important! Please read all instruction steps before you begin installation.

Step 1. Remove trim seal from housing.

Step 2. Slide cover down on housing as shown.

Step 3. Install the provided (x3) M6 screws back in place. Your install is now complete!

