



## INSTALLATION INSTRUCTIONS

**MAKE:** FIAT  
**MODEL:** 124 Spider  
**YEAR:** 2017 - 2020  
**ENGINE:** L4-1.4L (t)

**Axle-Back Exhaust**  
49-36901



**Caution:** aFe recommends professional installation on our products. Allow time for your vehicle to cool down prior to installation. When working on or under your vehicle proceed with caution. Exhaust systems reach high temperatures and may cause serious burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation.

- Step 1:** **(Read instructions prior to installation.)** Properly support your stock exhaust system (refer to your owner's manual for specific jack stand positions.)
- Step 2:** For faster installation spread the piece of the exhaust alongside your vehicle as shown in the diagram shown.
- Step 3:** Remove the stock muffler by unbolting it from the first flanged joint and removing it from the stock rubber isolation mounts.
- Step 4:** Using the provided bolts and nuts install the passenger side axle-back pipe and slide into the rubber isolation mount.
- Step 5:** Adjust system and begin tightening.
- Step 6:** Congratulations the installation of your exhaust is now complete. It is recommended to re-tighten all clamps and hardware 50-100 miles after installation.