

aFe Control

Front Suspension Strut Brace

Ford Explorer 20-22 L4/V6

Product Number: 450-30T002-G

Install Time: 10 Min. (Front Strut Brace),



Full Kit Contents	Front & Rear Sway Bar Set	Qty.
00P-0P2620-G	Strut Brace, Ford Explorer, Gray	1
00P-0P2618-N	Plate, Logo: Strut Bar, Orange	1
00P-0C1765-A	Nut: M4x0.7, nylon locking	2
00P-0C1766-A	Screw: M4x0.7x10, Pan Head Phillips, 18-8SS, Blk	2

Recommended Tools:

- Sockets: 7mm, 15mm
- Phillips Head Screwdriver
- Socket Wrench
- Torque Wrench

Installation:

1. Using the supplied 4mm hardware, install the logo plate onto the underside of the strut brace.
2. Using the 15mm socket, remove the 4 bolts and washers securing the OE Strut Brace. Retain Hardware for installation of aFe Control Strut Brace.
3. Install the strut brace with the hardware removed in step 2 and Torque to 22 ft lb (30 Nm)

