

aFe Control

Front Suspension Strut Brace

22+ Subaru BRZ/Toyota GR86

Product Number: 450-722001-G

Install Time: 10 Min. (Front Strut Brace),



Full Kit Contents	Front & Rear Sway Bar Set	Qty.
00P-0P2632-G	Strut Brace, Subaru Brz, Gray	1
00P-0P2618-N	Plate, Logo: Strut Bar, Orange	1
00P-0C1765-A	Nut: M4x0.7, nylon locking	2
00P-0C1766-A	Screw: M4x0.7x10, Pan Head Phillips, 18-8SS, Blk	2

Recommended Tools:

- Sockets: 7mm, 15mm
- Phillips Head Screwdriver
- Socket Wrench
- Torque Wrench

Installation:

1. Using the supplied 4mm hardware, install the logo plate onto the underside of the strut brace.
2. Using the 15mm socket, remove the nuts securing the struts to the chassis.
3. Install the strut brace with the hardware removed in step 2 and Torque to 23 Nm (17 ft-lb)

