

aFe Control

Front Suspension Strut Brace

14-18 Subaru Forester XT H4 2.0L ct)

Product Number: 450-731001-G

Install Time: 10 Min. (Front Strut Brace),



Full Kit Contents	Front & Rear Sway Bar Set	Qty.
00P-0P2634-G	Strut Brace, Subaru Forester	1

Recommended Tools:

- Sockets
- Socket Wrench
- Torque Wrench

Installation:

1. Remove the 4 outer flange nuts securing the struts to the chassis..
2. Install the strut brace with the OE Hardware and Torque to:
20 Nm (15 ft-lb) 2/4-door

