



advanced FLOW engineering

Dynamic Air Scoop D.A.S.

Instruction Manual P/N: 54-13056S / 54-13056SL / 54-13056SR

Make: Ford

Model: Ranger

Year: 2019-2023

Engine: I4-2.3L (t)

Make: Ford

Model: Ranger

Year: 2019-2023

Engine: I4-2.0L(td) Bi-Turbo



- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- For technical support please call 951-493-7185.
- Ensure you have all necessary tools before proceeding.
- Do not attempt to work on your vehicle when the engine is hot.
- Retain factory parts for future use.


Label	Qty.	Description	Part Number
A1	1	Scoop (Black)	05-5413056B3
A2	1	Scoop (Blue)	05-5413056L3
A3	1	Scoop (Red)	05-5413056R3


Installation will require the following tools:

T-30 Torx drive

Warranty Information available at: <https://afepower.com/contact#warranty>

Emissions Disclaimer: This product is not currently CARB exempt and is not available for purchase in California or for use on any vehicle registered with the California Department of Motor Vehicles.



**Figure A****Refer to Figure A for Step 1**

Step 1: Using a T30 Torx drive, remove the two screws ① holding down the air scoop ②. Remove the scoop and set aside.

**Figure B****Refer to Figure B for Steps 2**

Step 2: Install the aFe Dynamic Air Scoop using the two screws ③ removed in step 1. Tighten the screws.


NOTE: Check all screws are secure after 100-200 miles.



Page left blank intentionally



Page left blank intentionally



advanced FLOW engineering, inc.

252 Granite Street Corona, CA 92879

<https://afepower.com/contact>