

OMEGS25 GREASABLE SHACKLE KIT TOYOTA HILUX

HAND TOOLS REQUIRED

Ring / Open end Spanner set (Metric)
Socket Set (Metric)
Pry Bar
Torque Wrench

WORKSHOP TOOLS REQUIRED

Trolley Jack
Axle Stands
Lithium – Molybdenum grease
Grease Gun

OPTIONAL HAND TOOLS

Ratchet Spanners, 19 and 22mm

OPTIONAL WORKSHOP TOOLS

Vehicle Hoist

ITEM NUMBER	PART NUMBER	DESCRIPTION	QTY
1	3194835	SHACKLE PLATE OME HILUX BENT	2
2	3194837	SHACKLE PLATE OME HILUX TAPPED	1
3	3194836	SHACKLE PLATE OME HILUX	1
6	GSMP31	GREASABLE SHACKLE PIN (LONG)	2
7	GSMP30	GREASABLE SHACKLE PIN (SHORT)	2
8	5728013	GREASE NIPPLE	4
9	6151062	NUT M14 x 1.5	8
10	6151064	WASHER SPRING M14 x 5mm x 3 mm	8

Fitting Procedure – Refer to diagram Overleaf

1. Partially assemble shackle kit. Screw grease nipples into thread on pins then tighten with 8mm spanner. Place the plain ends of the pins into shackle plate. Fix pins in place with spring washers and nuts and finger tighten.
2. Jack rear of vehicle by chassis and secure axle with axle stands. Remove old shackle from spring eye and chassis mounts.
Note: Spare wheel may need to be partially lowered to allow sufficient space.
3. Remove Existing Bushes from chassis and spring eyes using pry bar.
4. Grease the inside and end face of new OME bushes with a Lithium based Molybdenum Disulphide grease. Once applied install the new bushes in the spring eye and chassis.
5. Install partially assembled shackle to chassis mount ensuring that the flat plates are on the outer most part on the chassis. Make sure the tapped flat plate is on the LHS of the vehicle.
6. Install the spring eye ensuring that grease nipples face to the outside of the vehicle.
7. Complete assembly by attaching other shackle plate to pins. Fasten with nut and spring washer. Once assembly is complete tighten and torque all fasteners to 81 Nm (59ft.lb).
8. Grease shackle assembly with Lithium based Molybdenum Disulphide grease using grease gun.

