



Installation

Kit P/N:

TR-2004P-D
TR-2004B-R

Make:

Lexus

Model: **Year:** **Engine:**

IS 250/250C	06-15	V6-2.5L
IS 350/350C	06-20	V6-3.5L
IS 300	18-20	V6-3.5L (AWD)

Note:

Includes F Sport

Parts Identification:

- 1 Air filter (**Pro Dry S™** TF-9007D)
- 1 Intake tube, 05-T2004P1
- 1 Housing, wrinkle black 05-T2004B2
- 1 Adaptor, 3-angle filter
- 1 Coupling, straight 05-00664
- 1 Coupling, reducer 05-00612
- 2 Clamp #048
- 1 Clamp #072
- 1 Clamp #060
- 1 Trim, rubber edge 1/16" @ 12"L
- 1 Trim, rubber edge 1/16" @ 24"L
- 3 Screws, button head
- 2 Flat washer M6
- 2 Hex screw M6
- 2 Screw M4 x .7 x 8

Tools Required:

- 10mm socket or wrench
- Ratchet w/ extension
- Phillips screw driver
- Flat head screw driver
- 5/16" nut driver
- Pliers
- 4mm allen key

Note: Read instructions before installation and have tools ready.



With 10mm socket and ratchet, loosen the two clamps using a 10mm socket or wrench from the OEM intake tube and airbox. Disconnect MAF sensor harness.



With 10mm socket or wrench loosen the 2 bolts holding in bottom half of air box and remove.



Complete Stock intake. Please disconnect battery terminals before installation.



Remove crank case line from stock intake tube.



Remove MAF sensor using phillips screwdriver.



Remove engine cover and front/passenger plastic covers.



Carefully remove stock air box assembly out of vehicle.



With provided M4 screws, install MAF sensor to new intake tube.



Accessories



Replacement Filter P/N:
TF-9007D



Pre Filter P/N:
TP-7011B

Note: Filter Cleaning: When cleaning your **Pro Dry S™** filter, be sure to use only "Restore Kit" (Takeda P/N: TP-7015C **Pro Dry S™** cleaner only.)

Pro Dry S™ cleaning:
see cleaning instruction sheet TF-9000I.

For replacement part(s) or "Restore Kit" please log on to takedausa.com
Corona CA, 92879

10



Attach adaptor to housing using button head screws provided. Attach trim seal to top of housing and cut out for scoop.

11



Position housing in the engine compartment.

12



Secure housing using provided screws and flat washers and tighten using 10mm socket or wrench.

13



Install intake tube with couplers and clamps provided. Do not tighten.

14



Re-connect MAF sensor harness and crank case line.

15



Tighten all clamps using 5/16" nut driver.

16



Install air filter and tighten using 5/16" nut driver.

17



Re-install all engine covers.
(Intake is shown with no plastic covers on)

18



The installation of your Takeda performance intake is now complete. Please check all components and re-tighten if necessary. Thank you for choosing Takeda!